



Ultra DriverPockets™ Phone Organizer

Instructions:

Attaching and adjusting the strap

- 1) With the hook at the top, slide the strap through the grommet (a) from the front to back, then feed it through the fabric loop (b) on the back
- 2) Position the organizer against the dash under the air vent then adjust the strap to desired length by bending the strap up over the fabric loop

Attaching the organizer to the vent

- 1) Slide hook end between to vent slats and twist slight to secure to slat
- 2) To remove, hold the base of the hook and push it into the air vent just enough to twist it free from the slat and pull

NOTE: excessive weight in the DriverPockets may cause vent panels to move and/or close

