



Driver Vent Caddy



Components:

② Bendable strap



① Vent Caddy

Instructions:

- 1) Slide bendable strap through slot on back of Driver Vent Caddy with hook at the top.
- 2) Holding the Vent Caddy, insert hook into vent and around a vent slat.
- 3) Slide the Vent Caddy up or down to your preferred position
- 4) Depending on your vent's orientation, twist the bendable strap so the Vent Caddy lies flat against the dash
- 5) Fold the bendable strap up behind the slot so the Vent Caddy stays in the right position. If the strap is visible above the top of the Vent Caddy, fold it down again.



Division of Talus Corp
Portland, ME 04103
Made in China
www.highroadorganizers.com

ZS-HR-3512