



# Digital Luggage Scale



## Specifications:

Maximum weight capacity: 40Kg / 88 lb

Minimum weight capacity: 1Kg / 2.2 lb

Units of measure: Kilograms / Pound weight (lb.)

Auto off feature

Low battery/ overload indicator

Uses 1 Lithium battery - included (CR2032)

## Usage notes:

- 1) When the display shows "Err", it means the scale is overloaded.
- 2) When the display shows "Lo", it means that the battery is low and needs to be replaced.
- 3) We recommend that you remove the battery to avoid possible damage to your digital scale from leakage if the scale is not used for an extended period of time.

## Instructions:

Please read carefully to ensure the correct operation of this product

### To replace battery:

- 1) Remove battery cover. Place a new 3V CR2032 in the battery holder and replace battery cover.
- 2) The LCD will display "888". After 3 seconds, the product will "beep" and the display will show "0.0kg".

### How to operate:

- 1) Press the "On/Off" button to turn on. The LCD will display "888", wait 3 seconds for a "beep", display will now show "0/0kg". Do not apply weight until after the display shows 0/0kg.
- 2) To weigh luggage, put the strap through the luggage handle and hook the metal clasp onto the base ring of strap. Clasp the handle of the scale securely and lift up with luggage attached. While lifting, scale will "beep" and display the luggage weight as well as a "hold" logo in the left bottom corner indicating the weight of the luggage is now "set".
- 3) To reset the data, press and release the "On/Off" button. Scale will "beep" and display will show "0/0kg" again.

- 4) Press the "On/Off" button to turn off. The scale will also power off automatically after 60 seconds to save power.

### To change kilograms to pound measure: (Kg/lb)

Press the "On/Off" button to turn on. The LCD will display "888" at startup, quickly press button to change the unit to KG or lb.